

INSTRUCTIONS

WEATHER-BRAKE

#307552123

**FITS: KUBOTA L2900, L3300, L3600
& L4200 WITH/W.O. LOADER**



GENERAL OFFICES

500 North 81 By-Pass
P.O. Box 1186
McPherson, Kansas 67460
Phone: (316) 241-3513
FAX: 1-316-241-3532
Toll Free: 1-800-677-0898


Subsidiaries

HINSON-FEMCO
JANTZ-FEMCO
FEMCO PLASTICS
AMERICAN PRIDE GOLF PRODUCTS

FORM NO. 286283100 / 9-95

IMPORTANT: READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE MOUNTING WEATHER-BRAKE. DO NOT TIGHTEN HARDWARE UNTIL INSTRUCTED TO DO SO.


STEP 1



YOKE BRACKET

1. Remove two (2) bolts from top of dash and save.
2. Attach yoke bracket (A) to top of dash using two (2) bolts removed.
3. **TIGHTEN BOLTS.**


STEP 2



DOOR POST

1. Remove front of left hand floor mat.
2. Attach door post (B) to holes in foot rest using two (2) M8 x 30mm bolts.
3. **TIGHTEN BOLTS.**


STEP 3



MOTOR COVER

1. Insert 3" hem on left side of motor cover down over door post.
2. Arrange motor cover over top of hood and down sides.

STEP 4



YOKE

1. Insert yoke (C) into top 3" hem of motor cover.
2. Attach yoke to yoke bracket using two (2) 1/4" x 1/2" bolts and nuts.


STEP 5



SIDE ARM REAR

1. Attach rear of side arm (D) to hole in fender using one (1) 1/4" x 3/4" bolt, fender washer and nut.


STEP 6



SIDE ARM FRONT

1. Attach front of side arm to bottom side of yoke using one (1) $1/4"$ x $3/4"$ bolt and nut. Bolt toward the bottom, nut on top.
2. **TIGHTEN ALL BOLTS.**

STEP 7



WINDSHIELD ASSEMBLY

1. Attach left and right window frames using two (2) #10 x $1/2"$ bolts and nuts.
2. Slide glass in channel of windshield frame.
3. Attach flat strip and angle strip to windshield frame using two (2) #10 x $1/2"$ bolts and nuts in second holes only.
4. **TIGHTEN BOLTS.**


STEP 8



WINDSHIELD ATTACHMENT

1. Attach assembled windshield to yoke and door post using one (1) $1/4"$ x $1"$ bolt and nut. Bolt toward the inside, nut on outside.
2. Attach other side of windshield to yoke using one (1) $1/4"$ x $1"$ bolt and nut. Bolt toward the inside, nut on outside.
3. **TIGHTEN BOLTS.**


STEP 9



RIGHT COVER

1. Arrange right cover over and around side arm and snap.
2. Locate hole in side arm and cut a hole in fabric at location (X).


STEP 10



VELCRO

1. Cut plastic velcro into 2" lengths.
 2. Surface must be cleaned with a mild detergent to assure proper application of velcro strips.
- NOTE:** Do not peel backing from velcro.
3. Apply cut velcro to all velcro sewn to motor cover.
 4. Arrange motor cover to tractor. Peel the back from the velcro and apply it to tractor. Repeat this procedure for all velcro.


STEP 11



DOOR

1. Locate holes in door post and cut holes in fabric.
2. Hold door (E) to door post and bottom of windshield.
3. Mark location of holes in door post to door.
4. Cut 5/8" slots next to wire frame of door and attach to door post using two (2) #10 x 3/4" bolts, nuts and clips.
5. Tie door flap (F) to motor cover.
6. **TIGHTEN BOLTS.**


STEP 12



LEFT WINDOW

1. Mark location of holes in windshield to left window (G).
2. Cut 5/8" slots next to wire frame of left window and attach to windshield using two (2) #10 x 3/4" bolts, nuts and clips.
3. Cut 5/8" slots next to wire frame of bottom left window and insert two (2) clips. **NOTE:** One in center and one towards rear.
4. Mark location for holes to be punched into fabric of door and punch holes.
5. Attach left window to door using two (2) #10 x 3/4" bolts and nuts.
6. **TIGHTEN BOLTS.**

STEP 13



RIGHT WINDOW

1. Mark the location of holes in windshield to right window (H).
2. Cut 5/8" slots next to wire frame of right window and attach to windshield using two (2) #10 x 3/4" bolts, nuts and clips.
3. Attach bottom of right window to side arm using one (1) 1/4" x 3/4" bolt and nut with two (2) 1/4" flat washers.
4. **TIGHTEN BOLTS.**

STEP 14 (Picture 1)




TIE STRAPS


IMPORTANT: Cloth straps are not to be attached to any moving, rotating or heat generating points of tractor. Any excess cloth strap is to be cut off.

1. Cut cloth strap to 12" length.
2. Thread the cloth straps through the grommets around loader area and tie to close off air gaps. (Picture 1)
3. Tie cloth strap to grommet at bottom of motor cover and then tie to tractor. (Picture 2)

STEP 14
(Picture 2)



STEP 15



DOOR LATCH

1. Remove handle from fender.
2. Attach door latch (I) to door latch bracket (J) using two (2) 1/4" x 3/4" bolts and nuts.
3. Position assembled door latch over front hole and reinstall handle.
4. Close door and position bottom of door in loop of door latch and align with door.
5. **TIGHTEN BOLTS.**