

INSTALLATION INSTRUCTIONS FOR

#1081 HINSON-FEMCO WEATHER BRAKE

FITS OLIVER 77, 88, 770, 880 COCKSHUTT, 770 ROW CROP (GAS or DIESEL)

Listed below are the special parts required for the proper installation of the 1081 Hinson-Femco Weather Brake. Carefully study the photo diagrams showing the location of each part. Follow the various steps numerically. Each part has Part Number stamped on it.

1 - #712100101 Yoke (A-1)

2 - #712110101 Side Arms (B-1)

2 - #712591901 Side Arm Brkts (V-19)

1 - #712590101 Mounting Brkt (V-1)




Figure 1

1. Bolt V-1 mounting bracket to steering column using U-bolt. See Figures 1 and 2. **DO NOT TIGHTEN TOO TIGHT.**
2. Bolt V-19 side arm brackets to axle brackets using $1/2" \times 1/4"$ hex head bolts. See Figure 1.
3. Insert B-1 side arms in wide hem on rear sides of canvas and the A-1 yoke in wide hem on top of canvas. Bolt B-1's to A-1 using $3/8" \times 1/2"$ hex head bolts and nuts. See Figures 1 and 2.
4. Place canvas over tractor and bolt A-1 to V-1 using $1/4" \times 3/4"$ hex head bolts. See Figures 1 and 2.
5. Bolt bottom of B-1's to V-19 brackets using $3/8" \times 1/2"$ hex head bolts and nuts. See Figure 1. Slide U-bolt up or down steering column until yoke is level, then tighten.
6. Straighten canvas and tie all straps adjusting with springs for a proper fit.




Figure 2






Figure 2

WINDSHIELD ASSEMBLY INSTRUCTIONS


1252
1258
1263



1. Slide glass in channel of windshield frame.
2. Assemble flat strip and angle strip to windshield channel using two $3/16"$ x $1/2"$ bolts in top holes and $1/4"$ x $1"$ bolts in lower holes. Tighten nuts.
3. Cuts slots in vinyl as shown in picture, insert F-1 clips in slots of R.H. curved side window. Secure this assembly to windshield channel frame with $3/16"$ x $3/4"$ bolts.



4. Install L.H. curved side window as in step No. 3.



5. Place windshield assembly on yoke so bolt in lower right hand corner of windshield fits into slot in yoke. Place hole in lower left corner over bolt in top of door post. Secure with wing nuts.
6. Secure right side window to rear edge of yoke as shown using flat lock washer and nut.

FEMCO, Inc.

GENERAL OFFICES
500 North 81 By-Pass
P.O. Box 1186
McPherson, Kansas 67460
Phone: 1-316-241-3513
FAX: 1-316-241-3532
Toll Free: 1-800-677-0898

Subsidiaries
HINSON-FEMCO
JANTZ-FEMCO
FEMCO PLASTICS
AMERICAN PRIDE
GOLF PRODUCTS